


MINERVA



MINERVA

WOOD

MV-141	Right upright post
MV-142	Left upright post
MV-171	Upper cross-member
MV-143	Side base
MV-101	Right front post
MV-102	Left front post
MV-103	Right back post
MV-104	Left back post
MV-111	Right upper lateral cross-member
MV-112	Left upper lateral cross-member
MV-113	Right lower lateral cross-member
MV-114	Left lower lateral cross-member
MV-150	Treadle set cross-member
MV-152	Back cross-member
MV-155	Breast or thread beam
MV-105	Cloth beam support
MV-164	Cloth beam w/ratchet wheel and canvas apron
MV-165	Warp beam with brake drum
MV-156	Batten handtree
MV-157	Batten sley
MV-2089	Shuttle race
MV-167-A	Front jack box board
MV-167-B	Back jack box board
MV-145	Jack box end (right or left)
MV-160	Cloth roller
MV-153	Jacks (pair, assembled)
MV-140	Lam
MV-130	Treadle
MV-2389	Right treadle set support
MV-2379	Left treadle set support
MV-135	Treadle spacer
MV-126	Brake treadle
MV-3639	Beam stick (replacing the canvas apron)

Metal

MV-4131	Harness frame without heddle support
3420-4131	Harness frame assembled
MV-422	Heddle support
MV-4299	Upper heddle support hook
MV-4279	Lower heddle support hook
MV-442	Jack iron-fitting
MV-429	Cloth roller support
MV-451	Jack axle rod
MV-452	Lam divider rod
MV-482-4	Treadle set; axle rod (4 harnesses)
MV-482-8	Treadle set axle rod (8 harnesses)
MV-491	Front hook to fold the loom
MV-492	Back hook to fold the loom
MV-495	Hinge
MV-493	Take up motion handle with ratchet pawl
MV-7	Ratchet pawl for. cloth beam (long)
MV-8	Ratchet pawl for cloth beam (short)
MV-10	Shaft for left side of the beam
MV-11	Batten sword
MV-14	Brake wire circle
MV-406	Strengthening piece for brake
MV-472	Brake lever
3000-5884	Brake spring

CAST-IRON

MV-1	Ratchet wheel
MV-2	Brake drum
3000-5892	Crank