

## NILEC

Please specify the dimension of the loom, 15" (38cm) or 15 3/4" (40cm) and give the serial number,

#### WOOD

- NC-B-1 Top cross-board
- NC-B-1-A Top cross-board with complete crank system
- NC-B-2 Right upright post
- NC-B-3 Left upright post
- NC-B-9 Upper lateral cross-member
- NC-B-S Lower lateral cross-member
- NC-B-6 Front, post
- NC-B-7 Back .post
- NC-B-8 Breast or thread beam
- Nc-B-9 Round cross-member
- Nc-B-10 Cloth or warp beam with ratchet wheel
- NC-B-11 Batten handtree
- NC-B-12 Batten sley
- NC-3639 Beam stick replacing the canvas apron)


#### METAL

- NC-4139 Harness frame without heddle support
- NC-422 Heddle support
- NC-A-2 Hook connecting harness to lever
- NC-A-3 Lever support
- NC-A-4 Complete crank system with lever
- NC-A-5 Lever stopper
- NC-A-6 Book to keep r loom in open position
- NC-A-7 Ratchet pawl for cloth beam (long)
- NC-A-8 Ratchet pawl for cloth beam (short)
- NC-A-9 Crank
- NC-A-10 Shaft for left side of the beam
- NC-A-11 Batten sword

#### CAST-IRON

NC-F-1 Ratchet wheel

DOROTHY



## DOROTHY

Leclerc produced 2 different models of Dorothy. The old one is 15" weaving width and the shaft frame outside width is 16 1/16".

The newest one is 15 3/4" weaving width and the outside width of the shaft frame is 16 7/8"

#### WOOD

- DT-B-1 Upright, post, with openings for levers
- DT-B-2 Upright post without opening
- DT-B-3 Front or back upper board
- DT-B-4 Upper lateral. cross?member
- DT-B-5 Lower lateral cross?member
- DT-B-6 Front post
- DT-B-7 Back post
- DT-B-8 Breast or thread beam
- DT-B-9 Round cross?beam
- DT-B-10 Cloth or warp beam with ratchet wheel.
- DT-B-11 Batten handtree
- DT-B-12 Batten sley
- DT-3639 beam stick (replacing the canvas apron)

#### METAL

- DT-4139 Harness frame without heddle support
- DT-422 heddle support
- DT-A-3 Hook connecting harness to lever
- DT-A-4 Shaft far lever catch
- DT-A-530 Lever with white tab
- DT-A-540 Lever with blue tab
- DT-A-550 Lever with yellow tab
- DT-A-560 Lever with red tab
- DT-4079 Shaft for levers (with nylon spacers)
- DT-A-6 Hook to keep loom in open position
- DT-A-7 Ratchet pawl for cloth beam (long)
- DT- A-8 Ratchet. pawl for cloth beam (short)
- DT-A-9 Crank
- DT-A-10 Shaft for left. side of the beam
- DT-A-11 Batten sword


#### **CAST-IRON**

DT-F-1 Ratchet wheel

#### PLASTIC

DT-P-2	Lever catch
DT-5102	White tab for lever






## MECO

A **medico** is a loom like the meco but the levers are on the front right hand side. **WOOD** 


WOOD	
ME-4131	Harness frame without heddle support
2320-4131	Harness frame assembled
ME-422	Heddle support
ME-4299	Upper heddle support hook
ME-4279	Lower heddle support hook
ME-A-16	V-shaped rod for harness frame
ME-4299	Hook connecting V-shaped rod to lever
ME-A-4	Shaft for lever catch
ME-A-530	Lever with white tab
ME-A-540	Lever with blue tab
ME-A-550	Lever with yellow tab
Mg-A-560	Lever with red tab
MĔ-A-6	Left hook to keep loom in open position
ME-A-6B	Brake lever ass. to right Hand side hook
ME-A-7	Ratchet pawl for cloth beam (long)
ME-A-8	Ratchet pawl for cloth beam (short)
ME-A-9	Crank
ME-A-10	Shaft for left side of the beam
ME-A-11	Batten sword
ME-A-12	Brake spring
ME-A-13	Brake wire extension (4 harnesses)
ME-4819	Brake wire extension (8 harnesses)
ME-A-14	Brake wire circle
METAL	
ME-4131	Harness frame without heddle support
2320-4131	Harness frame assembled
ME-422	Heddle support
ME-4299	Upper heddle support hook
ME-4279	Lower heddle support hook
ME-A-16	V-shaped rod for harness frame
ME-4299	Hook connecting V-shaped rod to lever
ME-A-4	Shaft for lever catch
ME-A-530	Lever with white tab
ME-A-540	Lever with blue tab
ME-A-550	Lever with yellow tab
Mg-A-560	Lever with red tab
ME-A-6	Left hook to keep loom in open position
ME-A-6B	Brake lever ass. to right Hand side hook
ME-A-7	Ratchet pawl for cloth beam (long)
ME-A-8	Ratchet pawl for cloth beam (short)
ME-A-9	Crank Shaft for left side of the beam
ME-A-10 ME-A-11	Batten sword
ME-A-12	Brake spring
ME-A-12 ME-A-13	Brake wire extension (4 harnesses)
ME-4819	Brake wire extension (8 harnesses)
ME-A-14	Brake wire circle
CAST-IRON	
ME-F-1 Ratche	twheel
ME-F-2 Brake	
	Lover estab
ME-P-2	Lever catch
ME-5102	White tab for lever
ME-5101	Blue tab for lever
ME-5104	Yellow tab for lever
ME-5103	Red tab for lever



## **MINERVA**

WOOD	
MV-141	Right upright post
MV-141 MV-142	Left upright post
MV-171	Upper cross-member
MV-143	Side base
MV-101	Right front post
MV-102	Left front post
MV-103	Right back post
MV-104	Left back post
MV-111	Right upper lateral cross-member
MV-112	Left upper lateral cross-member
MV-113	Right lower lateral cross-member
MV-114	Left lower lateral cross-member
MV-150	Treadle set cross-member
MV-152	Back cross-member
MV-155	Breast or thread beam
MV-105	Cloth beam support
MV-164	Cloth beam w/ratchet wheel and canvas apron
MV-165	Warp beam with brake drum
MV-156 MV-157	Batten handtree
MV-2089	Batten sley Shuttle race
MV-167-A	Front jack box board
MV-167-B	Back jack box board
MV-145	Jack box end (right or left)
MV-160	Cloth roller
MV-153	Jacks (pair, assembled)
MV-140	Lam
MV-130	Treadle
MV-2389	Right treadle set support
MV-2379	Left treadle set support
MV-135	Treadle spacer
MV-126	Brake treadle
MV-3639	Beam stick (replacing the canvas apron)
Metal	
MV-4131	Harness frame without heddle support
3420-4131	Harness frame assembled
MV-422	Heddle support
MV-4299	Upper heddle support hook
MV-4279	Lower heddle support hook
MV-442	Jack iron-fitting
MV-429	
	Cloth roller support
MV-451	Jack axle rod
MV-451 MV-452	Jack axle rod Lam divider rod
MV-451 MV-452 MV-482-4	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses)
MV-451 MV-452 MV-482-4 MV-482-8	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses)
MV-451 MV-452 MV-482-4 MV-482-8 MV-491	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long)
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short)
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8 MV-7 MV-8 MV-10 MV-11 MV-14	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short) Shaft for left side of the beam Batten sword Brake wire circle
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8 MV-7 MV-8 MV-10 MV-11 MV-14 MV-406	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short) Shaft for left side of the beam Batten sword Brake wire circle Strengthening piece for brake
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8 MV-70 MV-10 MV-11 MV-14 MV-406 MV-472	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short) Shaft for left side of the beam Batten sword Brake wire circle Strengthening piece for brake Brake lever
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8 MV-7 MV-8 MV-10 MV-11 MV-14 MV-14 MV-406 MV-472 3000-5884	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short) Shaft for left side of the beam Batten sword Brake wire circle Strengthening piece for brake
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8 MV-7 MV-8 MV-10 MV-11 MV-14 MV-14 MV-406 MV-472 3000-5884 <b>CAST-IRON</b>	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short) Shaft for left side of the beam Batten sword Brake wire circle Strengthening piece for brake Brake lever Brake spring
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8 MV-7 MV-8 MV-10 MV-11 MV-14 MV-406 MV-472 3000-5884 <b>CAST-IRON</b> MV-1	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short) Shaft for left side of the beam Batten sword Brake wire circle Strengthening piece for brake Brake lever Brake spring Ratchet wheel
MV-451 MV-452 MV-482-4 MV-482-8 MV-491 MV-492 MV-495 MV-493 MV-7 MV-8 MV-7 MV-8 MV-10 MV-11 MV-14 MV-14 MV-406 MV-472 3000-5884 <b>CAST-IRON</b>	Jack axle rod Lam divider rod Treadle set; axle rod (4 harnesses) Treadle set axle rod (8 harnesses) Front hook to fold the loom Back hook to fold the loom Hinge Take up motion handle with ratchet pawl Ratchet pawl for. cloth beam (long) Ratchet pawl for cloth beam (short) Shaft for left side of the beam Batten sword Brake wire circle Strengthening piece for brake Brake lever Brake spring

# INITIATION



## INITIATION

#### WOOD

- 2300-IT Upright post (right, or left)
- 2101-IT Right lateral cross-member
- 2201-IT Left lateral cross-member
- 3100-IT Right front post
- 2900-I1 left front post
- 1301-IT Back post (right or left)
- 3300-1T Treadle set cross?member
- 1702-IT Cross?member connecting upright posts
- 1105-IT Breast or thread beam
- 1801-IT Cloth beam with ratchet wheel
- 1901-IT Warp beam with ratchet wheel
- 2600-IT Batten sword
- 3000-IT Batten sword extension
- 2701-IT Batten handtree or batten sley
- 3700-IT Harness frame without heddle support
- 1008-2600 Harness frame assembled
- 3400-IT Treadle

#### METAL

- 2503-IT Heddle support
- 3808-IT Right stabilizing iron?fitting
- 3807-IT Left stabilizing iron?fitting
- 1804-IT Rod with nylon ends (cloth beam)
- 307-IT Ratchet pawl for cloth beam
- A-9-IT Crank
- 1704-IT Pulley axle rod (right of left)
- 2400-IT Middle pulley axle red (upper or lower)
- 1707-IT Paper quill covering lower middle pulley axle rod
- 1502-IT Treadle set axle rod

#### CAST-IRON

F-1-IT Ratchet wheel


#### PLASTIC

1120-IT Nylon pulley 1" dia.

#### CORDS

1609-10-IT Loop cords (ass.) connecting pulleys to shaft frames and treadles (set of 4)





## COMPACT 24"


WOOD	
18-CP	Right upright post (with harness guide)
17-CP	Left upright post (with harness guide)
1106-CP	Upper cross-member
206-CP	Right front post
207-CP	Left front post
208-CP	Right back post
209-CP	Left back post
211-CP	Treadle set cross-member
210-CP	Lower back cross-member
204-CP	Breast beam
205-CP	Thread beam
26-CP	Right cloth beam support (with bumper)
30-CP	Left cloth beam support (with bumper)
24-CP	Cloth beam with ratchet wheel
25-CP	Warp beam with brake drum
212-CP	Batten sword
2703-CP	Stop peg on batten sword
202-CP	Batten handtree
203-CP	Batten sley
22-CP	Harness frame without heddle support
1101-CP	Jack box board (front or back)
19-CP	Jacks assembled to lam (longer iron-fittings for harn. I-2
20-CP	Jacks assembled to lam (long iron-fitting for harness 3-4
135-CP	Jack spacer
2549-CP	Jack spacer (short)
2702-CP	Treadle set support
213-CP	Treadle
135-CP	Treadle spacer
214-CP	Brake treadle
1405-CP	Beam stick (replacing the canvas apron)
METAL	
422-CP	Heddle support
1203-CP	Upper heddle support hook
423-CP	Lower heddle support hook
1102-CP	Jack axle rod
215-CP	Treadle set axle rod
2801-CP	Iron-fitting connecting posts to upright post
1706-CP	Sliding plate receiving side handle
3200-CP	Take-up motion handle
2404-CP	Beam shaft
2908-CP	Beam machine bolt for crank
307-CP	front beam ratchet pawl
406-CP	Strengthening piece for brake
14-CP	Brake wire circle
472-CP	Brake lever
2806-CP	Brake spring
CAST-IRON	
2502-CP	Brake drum
2402-CP	Ratchet wheel
3000-5892	Crank
PLASTIC	
2803-CP	Side handle
2804-CP	Post iron-Fitting spacer
9259-CP	Beater bumper (upright post)
3300-9239	Sub-harness bumper


3300-9239	Sub-harness bumper


1702-CPHarness guide

CORDS 1022-2808

Brake cord







## ARTISAT 36"

WOOD	
141-AT	Right upright post
142-AT	Left upright post
143-AT	Right or left side base
166-AT	Castle top
101-AT	Right front post
102-AT	Left front post
103-AT	Right back post
104-AT	Left back post
111-AT	Right upper lateral cross-member
112-AT	Left upper lateral cross-member
113-AT	Right lower lateral cross-member
114-AT	Left lower lateral cross-member
152-AT	Middle lower cross-member
150-AT	Treadle set cross-member
155-AT	Breast or thread beam
164-AT	Cloth beam w/ratchet wheel and canvas apron
165-AT	Warp beam with brake drum
121-AT	Batten sword
156-AT	Batten handtree
157-AT	Batten sley
158-AT	Shuttle race
4500AT	Harness frame (w/o heddle support)
1009-4000	Harness frame assembled
168-AT	Harness upper part
169-AT	Harness lower part
167-AT	Jack box board (front or back)
145-AT	Jack box end (right, or left)
153-AT	Jacks (pair, assembled)
140-AT	Lam
2389-AT	Right treadle set support
2379-AT	Left treadle set support
130-AT	Treadle
135-AT	Treadle spacer Brake treadle
126-AT	
3639-AT <b>METAL</b>	Beam stick 36" (90 cm)
421-AT	Harness frame ends (pair)
4249-AT	Spring clip for harness frame end
422-AT	Heddle support
55-AT	Spring hook for heddle support
442-AT	Jack iron-fitting
451-AT	Jack axle rod
448-AT	Lam support
482-AT	Treadle set axle rod
4409-AT	Take-up motion handle support
493-AT	Take-up motion handle with ratchet pawl
3000-4701	Flat steel brake circle
4719-AT	Stengthening piece for brake
472-AT	Brake lever
3000-5884	Brake spring
480-AT	Shaft for left side of the beam
491-AT	Front hook to fold the loom
492-AT	Back hook to fold the loom
495-AT	Hinge (upper'or lower)
3000-4521	Treadle hooks (set of 6)
307-AT	Front beam ratchet pawl

## ARTISAT 36 (cont.)

#### **CAST-IRON**

# 311-ATBrake drum310-ATRatchet wheel3000-5892Crank

#### PLASTIC

6101-AT	Jack glide (harness guide)
6102-AT	Nylon for harness frame end
1109-AT	Stopper for brake treadle
3300-9239	Beater bumper (upright post)
0000 0010	

3000-9219 Sub-harness bumper

#### CORDS

- 3300-7513 Brake cord
- 3000-7011 Treadle cords (set of 12)
- 7719-AT Cord for beam 10 yards (9 m)

#### **ARTISAT 8S**

- 1311-AT Right upright post
- 1321-AT Left upright post
- 1363-AT Right side base
- 1373-AT Left side base
- 1481-AT Right jack box end (+ rods & bumper)
- 1461-AT Left jack box end (+ rods & bumper)
- 1399-AT Jack spacer
- 1339-AT Lam 36" (90 cm)
- 1353-AT Treadle with extension
- 1479-AT Treadle extension


#### METAL


- 1639-AT Jack axle rod
- 1709-AT Eyelet bolt with nut for jack iron-fitting
- 461-AT Back hook to fold the loom
- 1629-AT Treadle set axle rod
- 3501-4521 Treadle hooks 9" (23cm) (set of 10)

#### PLASTIC

1929-AT Rubber bumper for lam divider

# INCA





## INCA 36"

102 101	Dight upright past
-103-IN	Right upright post
104-IN	Left upright post
2589-IN	Castle top Jack-type
101-IN	Right front post
102-IN	Left front post
111-IN	Right upper lateral cross-member
112-IN	Left upper lateral cross-member
181-IN	Stop peg for beater
113-IN	Right lower lateral cross-member
114-IN	Left lower lateral cross-member
151-IN	Back cross-member
150-IN	Treadle set, cross-member
185-IN	Breast or thread beam support
155-IN	Breast or thread beam
164-IN	Cloth beam with ratchet wheel (without apron)
165-IN	Warp beam with brake drum
121-IN	Batten sword
184-IN	Batten sword spacer
156-IN	Batten handtree
157-IN	Batten sley
161-IN	Upper roller (w/o rod) Counter-Balance
162-IN	Lower roller (w/o pulley) Counter-balance
168-IN	Harness upper part
169-IN	Harness lower part
137-IN	Lam support
140-IN	Lam
131D-IN	Right treadle set support
1316-IN	Left treadle set support
130-IN	Treadle (with eyelets)
135-IN	Treadle spacer
126- IN	Brake treadle
177-IN	Stopper for brake treadle
191-IN	Beam stick (replacing the canvas apron)
Metal	
4249-IN	Spring clip for harness frame end
422-IN	Heddle support
423-IN	Hook for heddle support
427-IN	Hook for harness frame
4069-IN	Shaft for upper roller (Counter-balanced)
4169-1N	Pulley iron?fitting (Jack-type)
482-IN	Treadle set axle rod
493-IN	Take-up motion handle with ratchet pawl
307-IN	Front beam ratchet pawl
3000-5892	Crank
480-IN	Shaft for left side of the beam
4719-IN	Strenthening piece for brake
3000-4701	Flat steel brake circle
4819-IN	Brake wire extension
7103-IN	Brake spring (small)
7105-IN	Brake spring (large)
3000-4521	Treadle hooks (set of 6)

## INCA 36" (cont.)

#### Cast-iron

310-IN	Ratchet wheel
311-IN	Brake drum

#### Plastic

3300-9239	Beater bumper
9279-IN	Polyvinyl under-post
1113-IN	Nylon pulley
1110-IN	Pulley spacer
9319-IN	Rubber to prevent the cords slipping out from the pulleys

#### CORDS

7112-IN	Upper roller cords (set/2) Counter-Balance
7122- IN	Lower roller cords (set/4) Counter-Balance
1035-0000	Loop cords for roller (set/6) Counter-Balance
7312-IN	Cords connecting lams to harnesses (set/4) Counter-Balance
7369-72-IN	Loop cords (ass.) connecting lams to harn.(set/4) Jack
9819-IN	Loop cord for take-up motion handle

#### **INCA 8S**


#### WOOD

6349-IN	Cross-member for pulley frame (long)
6389-IN	Lateral cross-member for pulley frame (,port)
6409-INS	trengthening piece for pulley frame
6379-IN	Lam divider cross-member
6399-IN	Lam divider post
6429-TN	Lam divider spacer
6339-IN	Floating lam
6869-IN	Treadle extension

#### METAL

6649-IN	Pulley axle rod
( ( 0.0	

- 6639-IN Rod gor lam divider
- 6629-IN Treadle set axle rod



### MIRA - FANNY 36", 45" or 60"

#### **MIRA-FANNY**

MIRA-FANNY	
161-FN-MR	Upper roller (+ sockets & threaded rod)
162-FN-MR	Lower roller (+ plastic pulleys)
163-FN-MR	Upper roller socket
168-FN-MR	Harness upper part
189-FN-MR	Harness lower part
140-FN-MR	Lam
130-FN-MR	Treadle
135-FN-MR	Treadle spacer
123-FN-MR	Board to center ratchet pawls
3000-3672	Take-up motion handle with ratchet pawl
126-FN-MR	Brake treadle (old model using brake cord)
3000-3669	Brake treadle (new model)
METAL	
405-FN-MR	Roller support
476-FN-MR	Adjustment threaded rod (upper roller)
421-FN-MR	Harness frame ends (pair)
4249-FN-MR	Springy clip for. harness frame end
422-FN-MR	Heddle support
423-FN-MR	Hook for heddle support
427-FN-MR	Hook for harness frame
428-FN-MR	V?shaped rod for harness frame
448-FN-MR	Lam support
338-438FN-MR	Treadle set axle rod assembled to supports
406-FN-MR	Strengthening piece for take-up motion handle
407-FN-MR	Strengthening piece for ratchet pawls
417-FN-MR	Take?up motion handle support
412-FN-MR	Beam latch
4319-MR	Beam latch (buck)
3000-4701	Flat steel brake circle
403-FN-MR	Steel brake wire
4779-FN-MR	Strengthening piece for brake
4759-FN-MR	Brake lever
584-FN-MR	Brake turnbuckle
3000-5884	Brake springy
4789-Fn-MR	Rod connecting brake treadle to brake lever
418-FN-MR	Iron-fitting for batten sword
3000-4521	Treadle hooks (set of 6)

#### CAST-IRON

302-FN-MR	Plain wheel
303-FN-MR	Brake drum

#### FANNY

#### WOOD

- 141-FN Right upright post (w/o roller support)
- 142-FN Left upright post (w/o roller support)
- 103-FN Right back post w/o beam latch)
- 104-FN Left back post (w/n beam latch)
- 111-FN Right. upper lateral cross-member (without latch,
- 112-FN Left upper lateral cross.-member (without latch)
- 113-FN Right lower lateral cross-member
- 114-FN Left, lower lateral cross-member
- 151-FN Lower cross-member connecting back pasts
- (For the other parts see MIRA land FANNY)

#### METAL

461-FN Hook to fold back of the loom

## MIRA - FANNY 36", 45" or 60" (cont.)

MIRA - FANN WOOD	Y
141-MR	Right upright post (w/o roller support)
142-MR	Left upright post (w/o roller support)
101-FN-MR	Right front post
102-FN-MR	Left front post
103-MR	Right back post
104-MR	Left back post
111-MR	Right upper lateral cross-member (without latch)
112-MR	Left upper lateral crass-member (without latch)
113-MR	Right lower lateral cross-member
1 I4-MR	Left lower lateral cross-member
150-FN-MR	Treadle set cross-member
152-FN-MR	Back cross-member
155-FN-MR	Breast or thread beam
164FN-MR	Cloth beam w/ wheels & canvas apron
165-FN-MR	Warp beam with wheels
121D-FN-MR	Right batten sword (with iron-fitting)
1216-FN-MR	Left batten sword (with iron-fitting)
156-FN-MR	Batten handtree
157-FN-MR	Batten sley

#### Cast-iron

308-FN-MR	Ratchet wheel
3000-5862	Crank
306-FN-MR	Ratchet pawl for take-up motion handle
307D-FNMR	Ratchet pawl for cloth beam (short)
307LD-FN-MR	Ratchet pawl for cloth beam (long)


#### Plastic

1109-FN-MR Stopper for brake treadle 3000-9229 Beater bumper (upright post)

#### CORDS

4000-7113	Upper roller cords (set of 2)
3000-7123	Lower roller cords (set of 4)
1035-0000	Loop cords far rollers (set of 6)
3000-7519	Brake cord
3000-7011	Treadle cords (set of 12)





## NILUS 36", 45" or 60"


WOOD	
WOOD	Dight upright post
141-NU	Right upright post
142-NU	Left upright pest
166-NU	Castle top
101-NU	Right front post
102-NU	Left front past
103-NU	Right back post (w/o beam latch)
104-NU 111-NU	Left back post. (w/n beam latch)
112-NU	Right upper lateral cross-member (without latch) Left upper lateral cross-member (whithout latch)
113-NU	Right lower lateral cross-member
114-NU	Left lower lateral cross-member
150-NU	Treadle set, cross-member
152-NU	Middle lower crossmember
151-NU	Lower cross-member connecting back posts
155-NU	Breast or thread beam
164-NU	Cloth beam w/ wheels & canvas apron
165-NU	Warp beam with wheels
121D-NU	Right batten sword (with iron-fitting)
1216-NU	Left batten sword (with iron-fitting)
156-NU	Batten handtree
157-NU	Batten sley
158-NU	Shuttle race
168-NU	Harness upper part
168-NU	Harness lower part
167-NU	Jack box board (front and back)
2489-NU	Jack box end (right or left)
153-NU	Jacks (pair, assembled)
140-NU	Lam
130-NU	Treadle
135-NU	Treadle spacer
123-NU	Board to center ratchet pawls
3000-3672	Take-up motion handle with ratchet pawl
126-NU	Brake treadle (old model using brake cord)
3000-3669	Brake treadle (new model)
METAL	
421-NU	Harness frame ends (pair)
4249-NU	Spring clip far harm frame ends
422-NU	Heddle support
55-NU	Spring hank for peddle support
423-NU	Hook for peddle, support
442-NO	Jack iron fitting
451-NU	Jack axle rod
448-NU	Lam support
338-438-NU	Treadle set axle rod assembled to supports
406-NU	Strengthening piece for take-up motion handle
407-NU	Strengthening piece for ratchet pawls
417-NU 412 NU	Take-up motion handle support Beam latch
412-NU	
3000-47O1 403-NU S	Flat steel brake circle teel brake wire
403-NU S 4779-NU	Strengthening piece for brake
4759-NU	Brake lever
5874-NU	Brake turnbuckle
3000-5884	Brake spring
5000 0004	Drake spring

## NILUS 36", 45" or 60" (cont.)


METAL	
4789-NU	Rod connecting brake treadle to brake lever
461-NU	Hook to fold back of the loom
418-NU	Iron-fitting for batten sword
3000-4521	Treadle hanks (set of 6)
CAST-IRON	
302-NU	Plain wheel
303-NU	Brake drum
308-NU	Ratchet wheel
3000-5862	Crank
306-NU	Ratchet pawl for take-up motion handle
307D-NU	Ratchet pawl far cloth beam (shirt)
307LD-NU	Ratchet pawl far cloth beam (long)
PLASTIC	
6101-NU	Jack glide (harness guide)
6102-NU	Nylon for hardens frame end
1109-NU	Stopper far brake treadle
5000-9229	Beater bumper (upright post)
3000-9219	Sub-harness bumper
Cord	
3000-7519	Brake card
3000-7011	Treadle cords (set of 12)

#### NILUS 8S

2311-NU	Right upright post with ,lack box end
2321-NU	Left upright post with ,lack box end
2331-NU	Lam
2122-NU	Lam divider
1399-NU	Jack spacer
2419-NU	Treadle set support,
2392-NU	Treadle with extension
2439-NU	Treadle extension
135-NU	Treadle spacer
2429-NU	Brake treadle
METAL	
1639-NU	Jack axle rod
2639-NU	Treadle set axle rod
2649-NU	Brake lever
3501-4521	Treadle hooks 9" (23cm) (set of 10)



# NILUS II



## NILUS II 36", 45" or 60"

- 1300-NU II Right upright post 2300-NU II Left upright post 502-NU II Castle top Jack-type Right front post 1600-NU II 2500-NU II Left front post Right back post (w/o beam latch) 1800-NU II Left back post (w/o beam latch) 2700-NU II 1900-NU II Right stabilizing post 2800-NU II Left stabilizing post 1319-NU II Right upper lateral cross-member (without latch); Left upper lateral cross-member (whithout latch) 1329-NU II Right lower lateral cross-member 1401-NU II 1201-NU II Left lower lateral cross-member 202-NU II Treadle set, cross-member 152-NU II Middle lower cross-member 151-NU II Lower cross-member connecting back posts 205-NU II Cross-member connecting stabilizing posts 1669-NU II Breast or thread beam 164-NU II Cloth beam w/ wheels & canvas apron 165-NU II Warp beam with wheels 3500-NU II Right batten sword (with metal peg) Left batten sword (with metal peg) 3600-NU II 3100-NU II Batten handtree 157-NU II Batten slev 158-NU II Shuttle race 503U-NU II Right roller support 5036-NU II Left roller support C.B. 4801-NU II Shed regulator roller (w/ pulley) C.-B. 4802-NU II Shed regulator pulley C.- B. 4900-NU II Octogonal upper roller (+ plastic pulleys) C.-B. 5000--NU II Lower roller (+ plastic pulleys) C.-B. 168-NU II Harness upper part 169--NU II Harness lower part 1101-NU II Jack box board (front and back) Jack box end (right or left) 1102-NU II 1030-NU II Jacks (pair, assembled) 3300-NU II Lam Treadle set support, 403-NU II 4700-NU II Treadle 135-NU II Treadle spacer 123-NU II Board, to center ratchet pawls
- 3672-NU II Take-up motion handle with ratchet pawl
- 1404-NU II Brake treadle

## NILUS II 36", 45" or 60" (cont.)

#### METAL

- 208-NU II Hook to fold back of the loom
- 421-NU II Harness frame ends (pair)
- 4249-NU II Spring clip for harness frame end
- 422-NU II Heddle support,
- 55-NU II Spring hook for heddle support,
- 423-NU II Hook for heddle support
- 427-NU II Hook for harness frame
- 7106-NU II Spring for shed regulator
- 449-NU II Jack iron-fitting
- 451-NU TI Jack axle rod
- 446-NU II Lam Support
- 482-4-NU II Treadle set axle rod
- 406-NU II Strengthening piece for take-up motion handle
- 407-NU II Strengthening piece for ratchet pawls
- 417-NU II Take-up motion handle support
- 412-NU II Beam latch
- 3000-4701 Flat steel brake circle
- 403-NU II Steel brake wire
- 47797NU II Strengthening piece for brake
- 4729-NU II Brake lever
- 56747NU II Brake turnbuckle
- 3000-5884 Brake spring
- 4789-NU II Rod connecting brake treadle to brake lever
- 3502-NU II Peg for batten sword lower part
- 6839-NU IT Pin for shed regulator pulley
- 3000-4521 Treadle hooks (set of 6)

#### CAST-IRON

- 302-NU II Plain wheel
- 303-NU II Brake drum
- 308-NU II Ratchet wheel
- 3000-5862 Crank
- 306-NU II Ratchet pawl for take-up motion, handle
- 307D-NU II Ratchet pawl for cloth beam (short)
- 307 LD-NU II Ratchet pawl for cloth beam (long)

#### PLASTIC

- 6101-NU II Jack glide (harness guide)
- 6102-NU II Nylon for harness frame end
- 1109-NU II Stopper for brake treadle
- 3000-9229 Beater bumper (upright post)
- 3000-9219 Sub-harness bumper
- 7111-NU II Black rubber ring for rod connecting brake treadle to lever

## NILUS II 36", 45" or 60" (cont.)

#### CORDS

5102-NU II	Loop cords for shed regulator roller (set of 2)
5107NU II	Loop cords for shed regulator pulley
1035-0000	Loop cords for rollers (set of 6)
5111-NU II	Loop cords connecting harnesses to lams (set/4)
3718-NU II	Loop cords for stabilizing posts (set of 2)
3400-7011	Treadle cords (set of 12)

#### NILUS II 8S


#### WOOD


1100-NU II	Upright post (right or left).
------------	-------------------------------

- 3-NU IILam1400-NU IILam divider1399-NU IIJack spacer2300-NU IITreadle with extension2000-NU IITreadle extension
- 1604-NU II Brake treadle

#### Metal

1639-NU II	Jack axle rod
1709-NU II	Eyelet bolt with nut for ,lack ironfitting
4519-NU II	Treadle set axle rod
3501-4521	Ttreadle hooks 9" (23cm) (set of 10)





WOOD	
141-CL	Right upright, post (without batten support)
142-CL	Left upright post (without batten support)
146-CL	Right batten support
147-CL	Left batten support
146-CL	Strengthening piece for batten support
170-CL	Front upper cross-member
172-CL	Back upper cross-member
160-CL	Assembling peg
101-CL	Right front post
102-CL	Left front post.
103CL	Right back post (w/o beam latch)
104-CL	Left back post (w/o beam latch)
111-CL	Right upper lateral cross-member
112-CL	Left upper lateral cross-member
113-CL	Right lower lateral cross-member
114-CL	Left lower lateral cross-member
150-CL	Treadle set cross-member
152-CL	Middle lower cross-member
151-CL	Lower cross-member connecting back posts
167-CL	Middle crossmember connecting upright posts
155-CL	Breast or thread beam
164-CL	Cloth beam w/ wheels & canvas apron
165-CL	Warp beam with wheels
121-122-CL	Batten sword w/ attachment block
156-CL	Batten handtree
157-CL	Batten sley
156-CL	Shuttle race
173-CL	Horizontal roller support CB
177-CL	Vertical roller support CB.
162-CL	Adjustment peg for vertical roller support CB.
161-CL	Upper roller (w/ sockets)CB.
102-CL	Lower roller (w/ plastic pulleys) CB.
163-CL	Upper roller socket CB.
153-CL	Jacks (pair, assembled) Jack-type
135-CL	Jack spacer Jack-type
156-CL	Harness upper, part
169-CL	Harness lower part
140-CL	Floating lam
2551-CL	Right lam divider Jacktvpe
2552-CL	Left lam divider Jack-type
137-CL	Lam support Counter-Balance
131-CL	Treadle set support
130-CL	Treadle with extension
133-CL	Treadle extension
135-CL	Treadle spacer
181-CL	Stop peg for lower fixed beater
123-CL	Board to center ratchet pawls
125-CL	Take-up motion handle with ratchet pawl
126-CL	Brake treadle
176-CL	Hook to fold back of the loom
821-CL	Tip-proof stabilizers (pair)
1412-CL	Stabilizing board
1429-CL	Clamping member for stabilizing board

METAL	
442-CL	Jack iron-fitting
451-CL	Jack axle rod
421-CL	Harness frame ends (pair)
4249-CL	Spring clip for harness frame end
422-CL	Heddle support
55-CL	Spring hook for heddle support
423-CL	Hook for heddle support
427-CL	Hook for harness frame
482-4-CL	Treadle set axle rod (4 harnesses)
482-8-CL	Treadle set axle rod (8 harnesses)
416-CL	Treadle spring (with snap bodie)
425-CL	Support rod for treadle springs
406-CL	Strengthening piece for take-up motion hand:
407-CL	Strengthening piece for ratchet pawls
417-CL	Take-up motion handle support
412-CL	Beam latch
3000-4701	Flat steel brake circle
403-CL	Steel brake wire
4719-CL	Strengthening !piece for brake
472-CL	Brake lever
5874-CL	Brake turnbuckle
3000-5884	Brake spring
4789-CL	Rod connecting brake treadle to brake lever
3000-4531	Treadle hooks (set of 6)


#### Cast-iron

302-CL	Plain wheel.
303-CL	Brake drum
308-CL	Ratchet wheel
3000-5862	Crank
306-CL	Ratchet pawl for take-up motion handle
307D-CL	Ratchet pawl for cloth beam (short)
307LD-CL	Ratchet pawl for cloth beam (long)
Plastic	
1109-CL	Stopper for brake treadle

#### CORD


7113-CL	Upper roller cords (set of 2)
3000-7123	Lower roller cords (set of 4)
1035-0000	Loop cords for rollers (set of 6)
3500-7202	Cords connecting .lacks to lams (with chain at one end)(set of 4)
3500-7412	Cords connecting jacks to harnesses (set of 8)
3500-7312	Cords connecting lams to harnesses (set of 4)
3000-7529	Brake cord
3000-7011	Treadle cords (set of 12)

# COLONIAL I



# COLONIAL I

#### **Contre-balancé**



WOOD	
1119-CL I	Right upright post (w/o batten sword)
1129-CL I	Left upright past (w/o batten sword)
1539-CL I	Right batten support
1529-CL I	Left batten support.
148-CL I	Strengthening piece for batten support
1729-CL I	Upper cross-member (front or back)
1019-CL I	Right front post
	5
1029-CL I	Left front post
1079-CL I	Right back post (w/o beam latch)
1089-CL I	Left back post (w/o beam latch)
1319-CL I	Right upper lateral crass-member
1329-CL I	Left upper lateral crass-member
1339-CL I	Right lower lateral. cross-member
1399-CL I	Left lower lateral cross-member
1619-CL I	Treadle set cross-member
1629-CL I	Middle lower cross-member
1639-CL I	Lower crossmember connecting back posts
1659-CL I	Middle cross-member connecting upright posts
1669-CL I	Breast or thread beam
164-CL I	Cloth beam w/ wheels & canvas apron
165-CL I	Warp beam with wheels
2012-CL I	Right batten sword + iron-fitt. (low. fix. beater)
2032-CL I	Left batten sword + iron-fiat. (low. fix. beater)
2092-CL I	Right batten sword (overhead beater)
2052-CL I	Left batten sward (overhead beater)
2069-CL I	Batten handtree
2079-CL I	Batten sley
2089-CL I	Shuttle. race
2762-CL I	Horizontal roller support CB.
177-CL I	Vertical roller support CB,
182-CL I	Adjustment peg for vertical taller support CB.
161-CL I	Upper roller (w/ sockets) CB.
2629-CL I	Lower roller (with plastic pulleys) CB.
163-CL I	Upper roller socket CB.
153-CL I	Jacks (pair, assembled) Jack-type
135-CL I	Jack spacer Jack-type
2549CL I	Jack spacer (short) jack-type
168-CL I	Harness upper part
169-Ch I	Harness lower part
140-CL I	Floating lam
2551-CL I	Right lam divider Jack-ty
2552-CL I	Left lam divider Jack-type
137-C1 I	Lam support CB.
2373-CL I	Treadle set support
2349-CL I	Treadle
135-CL I	Treadle space
0-2329-CL I	Treadle set board (4 harnesses)
1-2329-CL I	Treadle set board (8 harnesses)
2-2329-CL I	Treadle set board (12 harnesses)
1922-CL I	Stoppers for overhead beater (pair)
181-CL I	Stop peg for lower fixed beater
3529-CL I	Board to center ratchet pawls
3672-CL I	Takeup motion handle with ratchet pawl
126-CL I	Brake treadle

175-CL I 821-CL I 1412-CL I 1429-CL I 1900-CL I 2800-CL I 205CL I <b>METAL</b>	Hook to fold back of the loom Tip-proof stabilizers (pair) Stabilizing board Clamping member for stabilizing board Right stabilizing post Left stabilizing post Crossmember connecting stabilizing posts
4249-CL I	Spring clip for harness frame end
422-CL I	Heddle support
55-CL I	Spring hook for heddle support
423-CL I	Hook for heddle support
427-CL I	Hook for harness frame
482-4-CL I	Treadle set axle rod (4 harnesses)
4828-CL I	Treadle set axle rod (8 harnesses)
482-12-CL I	Treadle set axle rod (12 harnesses)
416-CL I	Treadle spring (with snap bowie)
425-CL I	Support rod for treadle springs
406-CL I	Strengthening piece for take-up motion handle
407-CL I	Strengthening piece for ratchet pawls
417-CL I	Take-up motion handle support
412-CL I	Beam latch
3000-4701	Flat steel brake circle
403-CL I	Steel brake wire
4779-CL I	Strengthening piece for brake
4729-CL I	Brake lever
5874-CL I	Brake turnbuckle
3000-5884	Brake spring
4789-CL I	Rod connecting brake treadle to brake lever
418-CL I	Iron-fitting for batten sword
4531-CL I	Treadle hooks (set of 6)

#### CAST-IRON


302-CL I	Plain wheel
303-CL I	Brake drum
308-CL I	Ratchet wheel
3000-5862	Crank
306-CL I	Ratchet wheel for take-up motion handle
307D-CL I	Ratchet pawl for cloth beam (short)
307LD-CL I	Ratchet pawl for cloth beam (long)

#### PLASTIC

1109-CL I Stopper for brake treadle

#### CORD

7113-CL I	Upper roller cords (set of 2)
3000-7123	Lower roller cords (set of 4)
1035-0000	Loop cords for rollers (set of 6)
35007202	Cords connecting jacks to lams (with chain at one end) (set of 4).
3500-7412	Cords connecting jacks to harnesses (set of 8)
3500-7312	Cords connecting lams to harnesses (set of 4)
3000-7523	Brake cord
3000-7011	Treadle cords (set of 12)
3718-CL I	Loop cords for stabilizing posts (set of 2)



## KEBEC 90" or 100"

WOOD	
WOOD	
1119-KB	Right upright post (w/o lam support)
1129-KB	Left upright post (w/o lam support)
1689-KB	Upper cross-member holding pulleys
1059-KB	Right front post
1069-KB	haft front psot
1079-KB	'fight back post (w/o beam latch)
1089-KB	Left back post (w/o beam latch)
1.319-KB	Right upper lateral cross-member (without latch)
1329-KB	Left upper lateral cross-member (without latch)
1339-KB	Right lower lateral cross-member (w/o strengthening piece for batten sword)
1349-KB	Left lower lateral cross member (without " ")
1619-KB	Treadle set cross-member
1639-KB	Back cross-member
1819-KB	Breast or thread beam
3641-KB	Cloth beam w/ wheels & canvas apron
3651-KB	Warp beam with wheels
2011D-Kb	Right batten sword (w/ iron-fitting)
20116-K13	Left batten sword (w/ iron-fitting)
2069-KB	Batten handtree
2079-KB	Batten sley
2089-KB	Shuttle race
3889 -KB	Harness upper part
3899-KB.	Harness lower part
2411D-KB	Right lam
24116-KB	Left lam
2389-KB	Right treadle set support
2379-KB	Left treadle set support
2349-KB	Treadle
2359-1(B	Treadle spacer
2329-KB	Treadle set board
3529-KB	Board to center right ratchet pawls
3539-KB	Board to center left ratchet pawls
4301-3671	Right take-up motion handle with aluminum pawl
4302-3671	Left take-up motion handle w/cast-iron ratchet pawl
3669-KB	Brake treadle
METAL	
4300-2652	Large pulley (assembled)
4300-2642	Small pulley with hook
421-KB	Harness frame ends (pair)
4249-KB	Spring clip for harness-frame end
422-KB	Heddle support.
55-KB	Spring hook for heddle support,
423-KB	Hook for heddle support
427-KB	Hook for harness frame
6621-KB	Rod connecting center of batten handtree to batten sley
5022-KB	Iron-fitting for batten sword
5039KB	Strengthening piece for batten sword
6129-KB	Iron-fitting for breast beam
5419-KB	Lam support,
5432KB	Connector for center of lams
4519-KB	Treadle set 'axle rod
4719-KB	Strengthening piece for take-up motion handle
407-KB	Strengthening piece for ratchet pawls

## KEBEC 90" or 100" (cont.)


- 417-KB Take-up motion handle support
- 4319-KB Beam latch
- 403-KB Steel brake wire (specify the length of the wire)
- 4832D-KB Strengthening piece for brake (right)
- 48326-KB Strengthening piece for brake (left)
- 4729D-KB Brake lever (right)
- 47296-KB Brake lever (Left)
- 6700-KB Brake spring
- 4789-KB Rod connecting brake treadle to brake lever
- 3000-4521 Treadle hooks (set, of 6)

#### CAST-IRON

- 59054B Plain wheel for warp beam
- 5902-KB Brake drum
- 308-KB Ratchet wheel for cloth beam (right)
- 301-KB Ratchet wheel for cloth beam (left)
- 5862-KB Crank
- 4379-KB Ratchet pawl for right take-up motion handle (aluminum)
- 1172-KB Ratchet pawl for left take-up motion handle
- 307D-KB Ratchet pawl for cloth beam(short,right)(aluminum)
- 3076-KB Ratchet pawl for cl.oth beam (short, left)
- 307LD-KB Ratchet pawl for cloth beam(long,right)(aluminum)
- 307LG-KB Ratchet pawl for cloth beam (long, right)
- 4102-KB Stopper for brake treadle

#### PLASTIC

1302-KB Beater bumper (upright post)



## KEBEC II 4S Counter-Balance 100" or 120"

WOOD	
1300-KB II	Right upright post (w/o lam support)
1400-KB II	Left upright post (w/o lain support)
2901-KB II	Upper cross-member
1500-KB II	Right front post
2100-KB II	Left front post
1600-KB II	Right back post. (w/o beam latch)
2200-KB II	Left back post (w/o beam latch)
1801-KB II	Right upper lateral cross-member (without latch)
2401-KB II	Left upper lateral cross-member (without latch)
1339-KB II	Right lower lateral cross-member (w/o strengthening) piece for batten sword)
1349-KB II	Left lower lateral cross-member(without. " ")
202-KB II	Treadle set cross-member
1639-KB II	Back cross-member
5701-KB II	Breast of thread beam (round)
5704-KB II	Round piece for breast or thread beam end
5800-KB II	Cloth beam w/ wheels & canvas apron
5900KB II	Warp beam with wheels
3100-KB II	Right batten sword (w/ iron-fitting)
6600-KB II	Left batten sword (w/ iron-fitting)
2600-KB II	Batten handtree
2501-KB II	Batten sley
2089-KB II	Shuttle race
2800-KB II	Upper roller (with threaded rods)
2700-KB II	Lower roller (with metal pulleys)
4900-KB II	Screw to fix upper roller or jack support
3321-KB II	Jack support
3312-KB II	Jacks (pair, assembled)
3901-KB II	Harness upper part
4001-KB II	Harness lower part
5600-KB II	Floating lam
3400-KB II	Lam divider
2389-KB II	Right treadle set support
2379-KB II	Left treadle set support
6200-KB II	Treadle
259-KB II	Treadle spacer
2329-KB II	Treadle set board
3529-KB II	Board to center right ratchet pawls
3539-KB II	Board to center left, ratchet pawls
3871D-KB II	Right take-up motion handle with aluminum ratchet pawl
36716-KB II	Left take-up motion handle w/cast-iron ratchet paw
1709-KB II	Brake treadle
3500-KB II	Tension box adapter

## KEBEC II 4S Counter-Balance 100" or 120" (cont.)

METAL	
442-KB II	Jack iron-fitting
421-KB II	Harness frame ends (pair)
4249-KB II	Spring clip for harness frame end
422-KB II	Heddle support
55-KB II	Spring hook for heddle support
423-KB II	Hook for heddle support
427-KB II	Hook for harness frame
66'21-KB II	Rod connecting center of batten handtree to batten slew
5022 -KB II	Iron-fitting for batten sword
5039-KB 11	Strengthening piece for batten sword
5419-KB II	Lam divider support
3616-KB II	Chain connecting lam to harness frame
4519-KB II	Treadle set axle rod
4439-KB II	Strengthening piece for take-up motion handle
4739-KB II	Strengthening ,piece for ratchet pawls
417-KB II	Take-up motion handle support
4319-KB II	Beam latch
403-KB II	Steel brake wire (specify the length of the wire)
4832D-KB II	Strengthening piece for brake (right)
48326-KB II	Strengthening piece for brake (left)
4729D-KB II	Brake lever (right)
47296-KB II	Brake lever (left)
6700-KB II	Brake spring (large)
3000-5884	Brake spring (small)
1708-KB II	Hod connecting brake treadle to brake lever
1003-0304	Treadle hooks (set of 6)
Cootinen	
Cast-iron	Plain wheel for round breast or thread beam
5702-KB II	
5905-KB II	Plain wheel for warp beam
5902-KB II 5802-KB II	Brake drum Square toothed ratchet wheel
5862-KB II	Crank
4689D-KB II	Ratchet pawl for right take-up motion handle (aluminum)
46896-KB II	Ratchet pawl for left take-up motion handle
1170-KB II	Ratchet pawl for cloth beam(short,right)(aluminum
2410-KB II	Ratchet, pawl, for cloth beam (short; left)
1171-KB II	Ratchet pawl for cloth beam(long,right)(aluminum)
	Ratchet pawl for. cloth beam (long, left)
2411-KB II	Raichei pawi ioi. cioin beam (iong, ieii) Stepper fer brake treadle


4102-KB 11 Stopper for brake treadle

#### Plastic

1302-KB II Beater bumper (upright post) 0342-6102 Peg locking the treadle hook

#### Cord

1036-0000	Loop cords for rollers (set of 11)
3921-KB II	Cords connecting ,lacks to harnesses (set of 8)
3931-KB II	Cords connecting lams to harnesses (set of 4)
3400-7011	Treadle cords (set of 12)



## NILART 12 or 16s, 45" or 60"

WOOD	
141-NA	Right upright post
142-NA	Left upright post
166-NA	Castle top
101-NA	Right front post
102-NA	Left front post
103-NA	Right back post (w/o beam latch)
104-NA	Left back post (w/o beam latch)
111-NA	Right upper lateral cross-member (without latch)
112-NA	Left upper lateral cross-member (without latch)
113-NA	Right lower lateral cross-member
114-NA	Left lower lateral cross-member
150-NA	Front treadle set cross-member
152-NA	Middle lower cross-member
151-NA	Lower cross-member connecting back posts
155-NA	Breast or thread beam
164-NA	Cloth beam w/ wheels & canvas apron
165-NA	Warp beam with wheels
121D-NA	Right batten sword (w/ iron-fitting)
1216-NA	Left batten sword (w/ iron-fitting)
156-NA	Batten handtree
157-NA	Batten sley
156-NA	Shuttle race
168-NA	Harness upper part (with pins for harness weight)
169-NA	Harness lower part
167-NA	Jack box x board (front or back)
153-NA	Jacks (pair, assembled.)
1399-NA	Jack spacer
140-NA	Lam
143-144-NA	Lam divider
131-NA	Treadle set support
130NA	Treadle with extension
135-NA	Treadle spacer
132-NA	Treadle set board
123-NA	Board to center ratchet pawls
125-NA	Take-up motion handle with ratchet pawl
126-NA	Brake treadle
METAL	

421-NA	Harness frame ends (pair)
4249-NA	Spring clip for harness frame end
422-NA	Heddle support
55-NA	Spring hook for heddle support
423-NA	Hook for heddle support
419-NA	Harness weight - 6 oz (170 g)
5622-NA	Jack iron-fitting
5629-NA	Jack iron-fitting

### NILART 12 or 16s, 45" or 60" (cont.)

#### METAL

5619-NA	Jack axle rod (8-12 harnesses)
5619-16-NA	
	Jack axle rod (16 harnesses)
4519-8-NA	Treadle set axle rod (8 harnesses)
4519-12-NA	Treadle set axle rod (12 harnesses)
4519-16-NA	Treadle set axle rod (16 harnesses)
425-NA	Support rod for treadle springs
416-NA	Treadle spring (with snap bodie)
406-NA	Strengthening piece for take-up motion handle
407-NA	Strengthening piece for ratchet pawls
417-NA	Take-up motion handle support
412-NA	Beam latch
3000-4701	Flat steel brake circle
403-NA	Steel brake wire
4719-NA	Strengthening piece for brake
4729-NA	Brake lever
3000-5884	Brake spring
418-NA	Iron-fitting for batten sword
461-NA	Hook to fold back of the loom
32014521	Treadle hooks (set of 10)

#### Cast-iron

302-NA	Plain wheel
303-NA	Brake drum
306-NA	Ratchet wheel
304-NA	Crank
306-NA	Ratchet pawl-for take-up motion handle
307D-NA	Ratchet pawl for cloth beam (short)
307LD-NA	Ratchet pawl for cloth beam (long)

#### PLASTIC

6101-NA	Jack glide (harness guide)
6102-NA	Nylon for harness frame end
1109-NA	Stopper for brake treadle
3000-9229	Beater bumper (upright post)

#### CORD

3000-7529	Brake cord	
32007021	Treadle cords -	(set of 12)


#### NILART - TREADLE SET AT THE REAR

- 136-NA Right back lateral cross-member with short, post
- 1.37-NA Left back lateral cross-member with chart post
- 150-NA Hack treadle set crass-member
- 177-NA Cross-member with treadle divider
- 175-NA Back cross-member covering treadle divider
- 176-NA Bevelled cross-member supporting treadles
- 130P-NA Treadle with correction lever

#### METAL

6219-NA Hook connecting bank lateral cross-member to back past

# GOBELIN



# GOBELIN 36", 45" or 60" (80")

WOOD	
141-GB	Right front upright post
142-GB	Left front upright post
143-GB	Right back upright post
144-GB	Left back upright post
151-GB	Upper cross-member (front or back)
1629-GB	Lower cross-member
1619-GB	Treadle-set cross-member
111-GB	Right upper lateral cross-member
112-GB	Left upper lateral crass-member
115-GB	Cross-member for tension screw
114-GB	Right adjustable lateral cross-member
113-GB	Left adjustable lateral cross-member,
116-GB	Lower lateral cross-member
154-GB	Strengthening ,piece connecting cross-membe, to upright post
164-GB	Cloth beam with wheels
165-GB	Warp beam with wheels
161-GB	Heddle support
123-GB	Upper board to center ratchet pawls
124-GB	Lower board to center ratchet pawls
125-GB	Takeup motion handle
170-GB	Lease stick


#### METAL


6649-GB	Hook for heddle support
66n9-GB	Chain for heddle support
V50-GB	Tension screw (assembled)
406-GB	Strengthening piece for tike-up motion handle
407-GB	Strengthening piece for ratchet pawls
417-GB	Take-up motion handle support
4319-GB	Beam latch


#### Cast-iron

3U2-GB	Plain wheel
4939GB	Square toothed ratchet wheel
5662-GB	Crank
306-GB	Ratchet pawl for take-up motion handle
307-GB	Ratchet pawl for beam
	-

# TISSART







# TISSART

WOOD	
143-TS	Right front upright post
143-13 142-TS	Left front upright post
144-TS	Right back upright post (without beam latch)
141-TS	Left back upright post (without beam latch)
151-TS	Upper or middle cross-member
152-TS	Treadle set cross-member
154-TS	Shelf for tapestry accessories (+ iron-fitting)
111-TS	Right, lateral cross-member(whitout latch)
112-TS	Left lateral cross-member (without latch)
164TS	Upper warp beam with wheels
165-TS	Lower cloth beam with wheels and canvas apron
115-TS	Right harness slide
116-TS	Left harness slide
121-122D-TS	Right reed support
121-1220-TS	Left reed support,
170-TS	Harness axle cross-member
168-TS	Harness back part
169-TS	Harness front part
156-TS	Batten handtree
157-TS	Flatten sley
159-TS	Batten axle cross-member
129-TS	Right treadle support
131-TS	Left treadle support
130-TS	Treadle
135-TS	Treadle spacer
132-TS	Treadle set board
125-TS	Take-up motion handle with ratchet pawl
126-TS	Brake treadle
METAL	llownood from a and accompliant to right lower part of
<b>METAL</b> 421-461-TS	Harness frame end assembled to right lower part of
421-461-TS	left upper part of iron-fitt. for harn. frame end
	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of
421-461-TS 421-462-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end
421-461-TS 421-462-TS 4249-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end
421-461-TS 421-462-TS 4249-TS 422-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 464-465-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled)
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 467-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 466-TS 406-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 406-TS 4U7-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 406-TS 407-TS 417-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support
421-461-TS 421-462-TS 4249-TS 422-TS 422-TS 463-TS 463-TS 464-465-TS 466-TS 466-TS 466-TS 406-TS 407-TS 407-TS 417-TS 412-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch
421-461-TS 421-462-TS 4249-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 466-TS 406-TS 406-TS 407-TS 407-TS 417-TS 412-TS 3000-4701	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 466-TS 406-TS 406-TS 407-TS 417-TS 412-TS 3000-4701 4719-TS 3000-5884 469-TS I	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 407-TS 417-TS 417-TS 412-TS 3000-4701 4719-TS 3000-5884 469-TS I <b>Cast-iron</b>	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake Brake springy ron-fitting for tapestry accessories shelf
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 407-TS 417-TS 417-TS 412-TS 3000-4701 4719-TS 3000-5884 469-TS I <b>Cast-iron</b> 302-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake Brake springy ron-fitting for tapestry accessories shelf
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 406-TS 407-TS 417-TS 417-TS 3000-4701 4719-TS 3000-5884 469-TS I <b>Cast-iron</b> 302-TS 303-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake Brake springy ron-fitting for tapestry accessories shelf
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 406-TS 407-TS 407-TS 417-TS 3000-4701 4719-TS 3000-5884 469-TS I <b>Cast-iron</b> 302-TS 303-TS 308-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake Brake springy ron-fitting for tapestry accessories shelf Plain wheel Brake drum Ratchet wheel
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 407-TS 407-TS 417-TS 417-TS 412-TS 3000-4701 4719-TS 3000-5884 469-TS I <b>Cast-iron</b> 302-TS 303-TS 308-TS 5862-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake Brake springy ron-fitting for tapestry accessories shelf Plain wheel Brake drum Ratchet wheel Crank
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 406-TS 407-TS 417-TS 417-TS 417-TS 3000-4701 4719-TS 3000-5884 469-TS I <b>Cast-iron</b> 302-TS 303-TS 308-TS 5862-TS 306-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake Brake springy ron-fitting for tapestry accessories shelf Plain wheel Brake drum Ratchet wheel Crank Ratchet pawl for take-up motion handle
421-461-TS 421-462-TS 422-TS 422-TS 423-TS 463-TS 464-465-TS 466-TS 466-TS 406-TS 407-TS 407-TS 417-TS 417-TS 412-TS 3000-4701 4719-TS 3000-5884 469-TS I <b>Cast-iron</b> 302-TS 303-TS 308-TS 5862-TS	left upper part of iron-fitt. for harn. frame end Harness frame end assembled to right upper part of left lower part of iron-fitt. for harn. frame end Spring clip for harness frame end Heddle support Hook for heddle support Lever connecting harness axle to treadles Arm operating the batten (assembled) Batten spring Treadle set axle rod Strengthening piece far take-up motion handle Strengthening piece for ratchet pawls Take-up motion handle support Beam latch Flat steel brake circle Strengthening piece for brake Brake springy ron-fitting for tapestry accessories shelf Plain wheel Brake drum Ratchet wheel Crank